

966 BOOST - 988RR - XM 50

		A	B	C	D	E	L
anteriore - front - avant - vorder - anterior	HU6BB 966 BOOST	40,5	124,5	-	-	58	100
anteriore - front - avant - vorder - anterior	HU98B 988RR	35	9,5	-	-	58	100
anteriore - front - avant - vorder - anterior	HUX5 XM 50	35	19,5	-	-	58	110

		A	B	C	D	E	L
posteriore - rear - arriere - hinter - posterior	HU6BB 966 BOOST	-	-	36	21,5	58	148
posteriore - rear - arriere - hinter - posterior	HU98B 988RR	-	-	32,5	19,5	58	135-142
posteriore - rear - arriere - hinter - posterior	HUX5 XM 50	-	-	32,5	19,5	58	135-142

